

21 S2

HIGH-CAPACITY FOLDING MACHINES
AND DISPENSING SYSTEMS

Leaflet Folding Machine

Stand-alone machine for individual use

FA 21/4-S2
CARTONAC 2000-2SOLO
SERIES**GUK-Falzmaschinen**

Griesser & Kunzmann GmbH & Co. KG

Bahnhofstraße 4 · D-78669 Wellendingen · Tel. +49 (0) 74 26 - 703 - 1

info@guk-falzmaschinen.de www.guk-falzmaschinen.com

FA 21 S2 SOLO-SERIES

UNIVERSAL SHORT RUN FOLDING MACHINE

QUICK FORMAT CHANGE WITH SIMPLE OPERATION AND RELIABILITY THROUGH CODE READING

The ideal compact machine for every folding issue in the inserting section. An independent model for the folding of short runs and big quantities. Easy to handle with batch counter and code reader for safe identification of the folding samples. Table length 600 m with air nozzles suspension.

TECHNOLOGY

The well-approved folding technology of the CARTONAC 2000 series makes this machine a productive support and an investment adding high technological value.

Suitable for a great variety of different print sizes. Simple placement of the folding material during operation, sheet removal from the bottom. Uninterrupted folding without machine stop. Possibility to integrate code-reading from the bottom or top. Smallest finished size 60 x 15 mm.



OPTIONS

Electronic pocket adjustment. Quick and easy roller adjustment with digital display.



>>> **INFOBOX**

FEATURES	TECHNICAL DATA	
<ul style="list-style-type: none"> ❑ Exact sheet separation by suction roller ❑ Reading section for code reading ❑ A pair of outfeed scoring shafts ❑ Quick roller adjustment ❑ Electronic folding pocket set-up (opt.) ❑ Ejection device with code-reading unit (opt.) ❑ Touch-Control for automatic roller and pocket settings ❑ Easy to maintain due to the outside drive ❑ Paper 40-80 gr., according to specifications ❑ Format improvement by dynamic draw-off (opt.) ❑ Combination roller of steel and rubber 	<p>Folding mechanism</p> <hr/> <p>Output (sheets/min.)</p> <hr/> <p>Formats (with options)</p> <hr/> <p>Drive</p> <hr/> <p>Options</p> <hr/> <p>Models</p>	<p>215 mm infeed width, 4 or 6 folding pockets</p> <hr/> <p>max. 500/min. at format length up to 320 mm max. 200/min. at format length over 320 mm</p> <hr/> <p>min. (WxL): 60 x 90 mm typ. (WxL): 178 x 320 mm max. (WxL): 215 x 600 mm</p> <hr/> <p>Base module with independent drive and control panel (S2), movable base (opt.)</p> <hr/> <p>Optional extended folding pocket 1, all-around V2A cover, electronic roller adjustment, etc.</p> <hr/> <p>FA 21/4-S2 CARTONAC 2000-2 FA 21/6-S2 CARTONAC 2000-2</p>