

FA



21 S2

HIGH-CAPACITY FOLDING MACHINES
AND DISPENSING SYSTEMS



Leaflet Folding Machine

Stand-alone machine for individual use



FA 21/4-S2
SVA 730

SOLO SERIES



GUK-Falzmaschinen

Griesser & Kunzmann GmbH & Co. KG

Bahnhofstraße 4 · D-78669 Wellendingen · Tel. +49 (0) 74 26 - 703 - 1

info@guk-falzmaschinen.de www.guk-falzmaschinen.com

FA 21 S2 SOLO-SERIES

UNIVERSAL SHORT RUN FOLDING MACHINE



QUICK FORMAT CHANGE WITH SIMPLE OPERATION AND RELIABILITY THROUGH CODE READING

The ideal compact machine for every folding issue in the inserting section. An independent model for the folding of short runs and big quantities. Easy to handle with batch counter and code reader for safe identification of the folding samples.

TECHNOLOGY

More than 1000 times approved, the folding mechanism of the CARTONAC 91 models makes this machine a good investment. It is made for a large spectrum of print runs. Simple feed during running as the sheets are taken from the bottom of the stack. Continuous non-stop folding.

>>> INFOBOX

FEATURES	TECHNICAL DATA	
<ul style="list-style-type: none"> ■ Takes the sheets from the bottom ■ Code reading possible (opt.) ■ Accurate roller adjustment ■ Maintenance-free pockets ■ Transfer belts (opt.) ■ Combined steel and rubber rollers ■ V2A execution (opt.) ■ Ejection device (opt.) ■ Independent control device (opt.) 	Folding mechanism	210 mm infeed width, 4 or 6 folding pockets
	Output (sheets/min.)	max. 350/min. at format length up to 320 mm max. 100/min. at format length over 320 mm
	Formats (with options)	min. (WxL): 60 x 90 mm typ. (WxL): 160 x 320 mm max. (WxL): 210 x 650 mm
	Drive	Independent Drive (S2)
	Options	Extended folding pocket 1, 450/575/650 mm stacking table with air nozzle, and mobile base etc.
	Models	FA 21/4 S2 SVA/730 FA 21/6 S2 SVA/730